



WHITLOCK
BULL BARS

F1828

FIAT

DUCATO

2014 TO 2019

FITTING INSTRUCTIONS



BOLT KIT

8 = M10 X 40MM BOLTS
8 = M10 FLAT WASHERS
8 = M10 SPRING WASHERS

6 = M6 X 30MM BOLTS
12 = M6 FLATWASHERS
6 = M6 NYLOC NUTS

X 2 M10 NUT PLATES

Lift side step into place ensuring it is level. Mark holes into body of vehicle.



Drill holes into body of vehicle using M10 drill bit. Nut plate will be inserted into body of vehicle as shown.



Remove plastic cap highlighted in yellow to be able to fit nut plate inside body as shown. Drill body with M10 drill bit in previously marked places.



Re-lift side steps back into place and bolt M10 bolts through side steps and body in to nut plates as shown previously. Drill 3 X 6MM holes through flange of side step into body of vehicle and bolt in with supplied 6MM bolts. The holes will already be pre drilled into side steps. Repeat process on other side for second step.





**Congratulations YOU HAVE
FITTED Your NEW**

**F1828
WHITLOCK
BULL BAR**



WHITLOCK
BULL BARS

CLIENT REVIEWS

Share Your Experience:

We'd love to hear about your experience! Share your feedback and photos of your truck with your portrait with the bull bars installed by emailing us at sales@whitlockbullbars.com.au



SCAN QR CODE
**HAVE
YOUR SAY**



FRONT



ISOMETRIC

WHITLOCK BULL BARS TAKE PRIDE IN PROVIDING HIGH-QUALITY BULL BARS THAT NOT ONLY ENHANCE THE LOOK OF YOUR TRUCK BUT ALSO PROVIDE UNPARALLELED PROTECTION.

YOUR FEEDBACK HELPS US IMPROVE OUR PRODUCTS AND SERVICES TO BETTER SERVE YOU.